LIST of PARTS



MACHINE No. 114-21

THE SINGER MANUFACTURING COMPANY

COPYRIGHT, U. S. A., 1917, 1922, 1924 AND 1928, BY THE SINGER MANUFACTURING CO. ALL RIGHTS RESERVED FOR ALL COUNTRIES

INDEX

	PAGE
Accessories	. 16
FOOT LIFTER CHAIN GUIDE	. 17
" PARTS	17
Machine No. 114-21	7
Numerical List of Parts	21
STARTING LEVER	18
TABLE BELT GUIDE	18
THREAD UNWINDER	18

•

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed

B-Polished, Nickel Plated and Buffed

C-Hardened Only

D-Polished Only

E-Soft, Not Polished

F--Hardened and Polished

H--Blued

1-Nickel Plated Only

K-Hardened and Nickel Plated

L-Brass Plated

M--Oxidized

P--Japanned

R -Merlized

T-Copper Plated

T. A.—Hardened, Polished, Copper and Nickel Plated and Buffed.

T. B. -- Copper and Nickel Plated and Polished.

T. J.—Copper and Nickel Plated Only.

T. K.-Hardened, Copper and Nickel Plated.

T. M.—Copper Plated and Oxidized.

T. L.—Copper rated and Oxidiz T. L.—Copper and Brass Plated.

U-Zinc Plated

V—Silver Plated

W-Polished and Nickel Plated

Z-Chromium Plated

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

1 to 1500 and 50001 to 51500 are Screw Numbers.

1501 to 1800 and 51501 to 51800 are Nut Numbers.

1801 to 2000 and 51801 to 52000 are Roller Numbers.


2001 to 50000 and 52001 and upward are numbers of Machine Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

134

LIST OF PARTS COMPLETE



MACHINE No. 114-21

FOR TACKING BANDS AND BOWS ON FELT DR STRAW HATS.

MAKES FIVE STITCHES, INCLUDING THE FASTENING
STITCH; HAS DDUBLE PRESSER FOOT, HINGED SO THAT
EITHER SIDE CAN BE THROWN DUT FOR CONVENIENCE
IN TACKING THE BOWS. FITTEO WITH IMPROVED THREAD
CONTROLLING MECHANISM AND THREAD NIPPING DEVICE
TO HOLO THE END OF THE THREAO UNTIL THE FIRST
STITCH IS MAGE.

	,,, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
NO.	PLATE			NAMI		
*62201		Arm			3 and two 16	
16532	6976	4.6				
4448	6976	"	Oil Tul	oe, for inter	rmediate bes	ring
56015	6976	"		" oilin	ig 59705 and	d 59706
8801	9074	"	Screw.			
59702	9073		Shaft (horizontal)	
17703	9062	"	"	"	Bushing	
503330	: 9074	44	"	"	"	"
		Ac	ljusting	Screw		
15201	9075	Arm	Shaft	(horizonta	al) Bushing	(back)
		Α	ljusting	Screw Nu	ıt.,	
*4449	9062	Arm	Shaft (horizontal)	Bushing (fr	$\operatorname{cont})$
59703	6976	46	"	"	Gear wit	thtwo
		10	36c			

NO. PLATE	NAME
1036c - 6976	Arm Shaft (horizontal) Gear Set Screw
59704 6976	" " (upright)
59705 6976	" " Bushing (lower)
448c 6992	" " " Set
1100 0002	Serew
59706 6976	Arm Shaft (upright) Bushing (upper)
448c 6992	" " Set
4480 0002	
FOROR (1074)	Screw
59707 6976	
1050 4054	two 1253c
1253c 6976	Arm Shaft (upright) Gear (lower) Set
	Screw
59708 - 6976	Arm Shaft (upright) Gear (upper) with
	two 1253c
1253c 6976	Arm Shaft (upright) Gear (upper) Sct
	Screw
124674 - 9062	Arm Side Cover
190b 9074	" " Screw
18498 9073	Belt Cover
59795 9063	" Bracket with 184E and 59796
184E 9074	" " Serew Stud
59796 9062	" " Stud
217p 9074	" " Screw
3 9222 9063	" Shifter
63976 9062	" " Clamp
1255p 6976	" " Screw
*62202	Cylinder
62203 9063	" Bottom Cover
330р 9078	" " Serew
62204 9063	" End Cover
62205	" " 62204 with 1034p,
02200	62111, 62203, 62206 to 62208 and four
	1477p
62206 9062	Cylinder End Cover Bracket
62206 9062 62111 9062	" " " " Hinge Pin
	" " Screw
1477b 9074	ocrew
62207 9062	ringe
1477b 9074	Screw
62208 9062	spring
1034ъ 9074	Screw
124939 9063	Face Plate
124940	Face Plate complete, Nos. 208n, 392E,
	442c, 1550c, 9544, 9545, 62211, 62212,
	124939, two 9543 and three each 229p
	and 2107
190ь 9074	Face Plate Screw (lower)
164ъ 9074	" " (upper)

NO.	Pi	ATE				NAME			
2107		0062	Face 1	Plate	Thread	l Guard			
2291	-		"	44	44	44		/. .	
62211		0062		"	"	Nipper	Disc.		
62211	•	0062	44	"	44	"	44	Cov	
3921			46	44	"	"	44	"	
3921	, i	707-1	Ser	0.337					
20019		0062	Engo	Diate	Thread	ł Nippe	r Sprii	ng	
62213		9002	44	112110	44	46	"	Scre	w
857		9074 - 9062		"	66	Retair	ner Dis	sc	
9543		9062	46	"	"	"	"		ver
9544		-	44	44	44	44	"		"
208	D	9074	No.						
		0000	Der	DL+	Thros	d Reta	iner D	isc Sr	ring
9545		9062	Face	Tau	; I mes	two 11	02a s	oven	each
62215		9073	Feed	Can	With	14000 m	920, s	nt oon	335#
			190)o, 17	874, 1	24638 a	na iou	1.441.0	and
18415		9064	Feed	Cam	Drivin	g Worm	with	14410	and
			14	12c					
1442	c	9064				g Worm			
1.141	C	9064	44	**	44	"	.,	crew.	
17797	,	9063	+4	"	44	"		with	
3012	2	9062	**	44	44	.4	"	Pin	
453	ic.	907-1	**	•6	"	"	"	Set S	bcrew
1838		9062	44	44	Pin				
		907-1	44		Set Sc	rew			
62158		9065	44		Shaft.				
165			+ 6	44	44	Nut			
12494		9070	14	Plat	c				
62293		9065		46		er Bar			
6229			**	"	44	" 6	2292	with	$199\mathbf{p}$
0220	,		911	d-625	222				
6229	1	9061	Foor	l Plat	e Carr	er Bar	Plate.		
	_	9074			"	"		Screw.	
		9074	63	"	"	"	Screw.		
				"	Sero				
		9074		Ď		with 19			
1774		9065		пср	guiator	Bracke			
6222	1	9065	•	1.0	0				
			t t	vo 16	OD	1) - 14	Con		
*1773				d Rep	gulator	Bracket	Cap.	Screw	
		9074			"	"			
858		906-	_					el Pin	
90	5 5ι	907-			"	"		w	
1774	1-1	906			"	Hinge S	Stud		
6222	22	906				Post			
193	53	906	1 "		44	Roller			
			W	rith 1	655c aı	nd 1401	7		
16	55	c 906	4 Fee	ed Ro	egulato	r Rollei	and	Screw	Stud
			N	lut					

NO. P	LATE			NAME		
	9064	Feed	Regul	ator Roller	and Seres	y Stud
				er		
1190c 9	9074	Feed 1	Regula	tor Stop Scr	ew	
17745	9064	44	"			
1191в 9	9074	"	"		Screw	
62266	9066	Guide				
602p 9	9074	**	Adjus	ting Screw		
62267	9066	44		r		
76b 9	9075	64	* 6	Hinge Sere		
62268	9066	44	"	Lock Sprin		
62269 - 9	9065	Hat S	upport	··············		
92n 9	0075	44	**	Hinge Screv	v	
62270 - 9	9064	44	"	Lock		
100n (075	"	44	" Screw		
124654 9	9064) with 12465	5 and two	1380p
124655	9064	44	44	Thread Gu	ard	
1380ъ 9	0064	"	"	"	" Screw	
1329n 9	9074	"	"	Screw		
124656	9064	"	(upper	•)		
36634	9064	"	"	Friction W	asher	
50316b 9	9075	44	"	Hinge Sere	:w	
	3064	44	"	Spring	<i></i>	
190b (0074	"	"	" Ser	ew	
	9073	44	Bar			
	9064	"	44	Cap (back))	
	0064	"	"	"	Screw	
	9066	"	"	Connection		
190в 9		"	"	"	Screw	
	9066	"	"	"	Slide Blo	
17917 -						17915
17010 (2000			5		
	9066	Knife		Connection 8		
59734	9066		,	Oriving Leve		
1200 (3075		35			
1382r 9 1681c 9		Knife	Dar I	Driving Lev		Screw
10010 8	9073					••
59735	9066	IN UU	D 13	riving Lever	Γ. 1. O.	
	9066 9066	Kinge	Date 1)	" Lever	LOCK Stu	
220F ;	,000	Samo				Set
124748 9	0066					
)066	Kone	oar R	etaining Spri		
	9067	"	Lovor	•	DIACKE	
	0064	"		Block		
	9064	44	"			
	075	"	"	Hinge Screw		
194c 9		"		eringe Screw Screw Stud		
1010 8	OUT			outen pula		

NO.	PLATE			NAM	ſΕ		
62298	9067	Looper	with	34418			
*59742		"		r			
50150c	9074	46	Set S	erew			
62231	9073	44	Shaft	with 501	50c an	d 59742	2
62131	9067	44	44	Bushing	(back))	
62285		"	"	"	"	62131	
447c	9074	Looper	Sbaft	Bushing	(baek)	Set Scre	e w
62233	9067	"	44				
124694		"	"	"	"	62233	with
447c	9074	Looper	Shaft	Bushing	(front)	Set Scr	ew
52045	9067	66	"	"	Oil Pac	d (cotto	n)
59745	9067	"	"	Collar w	ith two	465c	
4650	9067	"	"	" S	et Serev	v	
59707	6976	"	"	Gear wit	h two 1	1253c	
59747	6992	**	"	" Co	ver	. .	
1901	9074	"	44	"	" Ser	cw	
12530	6976	44	44	" Set	Screw		
34418	9067	-66	Was	her			
124942	9069	Needlo	Bar	with 904			
*39203	9067	44		Connectin			
62283		44	"	"	"	39203	
		377 c	, 1518	SE and 20	52		
377	6992	Needle	Bar	Connecti	ng Link	Hinge	Serew
15181	6992	"	46	"	"	44	. "
		Nut					
2052	6992	Needlo	Bar (Connectir	ng Stud	with 15	5с
1550	6992	46	"	4.6	"	Set Scr	
62235	9068	44	44	Crank W	/heel_w	rith 446	ic and
		1293	Вс				
1293c	: 6992			Crank Wl		sition Sc	rew
4466	9067	66	66	"	" Set	Screw.	
124943	9068	"	"	Thread N	ipper.		
1329	€ 9074	"	"	44	" S	crew	
62271	9057	"	Gua	rd (back)	with ty	vo 465c	
62272	9067	46	"	"	Cam v	with tw	o 465c
465	c 9067	44	"	"	"	Set Sere	w
465	c 9067	44	"	"	Set Se	:rew	
62236	9067	44	44	46	Shaft		
62238	9067	44	44	"	"	Bushin	
447	c 9074	44	46	44	44	"	Set
		Sere	ew				
59761	9067			ard (back			
465	c 9067	Needl	e Gu	ard (bae	k) Sha	ft Coll	ar Set

NO. PLATE	NAME
62273 9067	Needle Guard (back) Shaft Crank with
02210 3001	1816
0070 0070	Needle Guard (back) Shaft Crank Pin
2273 9076	" " " " Roller
1816 9067	Konei
	and Stud
62239 - 9068	Needle Guard (back) Shaft Crank Spring
62274 - 9068	" " (front)
190p 9074	Screw
904c 9074	" Set Screw
62275 - 9068	Presser Bar
17841 - 6992	" Collar with two 196F
196F 6992	" " Set Screw
47842 - 6992	" Guide Bracket with 453c
453c 9074	" " Set Screw
17843 - 9069	" Lifting Lever
124793 - 9068	" " " Bracket
164 = 9074	" " " Screw
1201p 9075	" " " " Hinge Screw
17845 - 9069	" " " Rod
39408	" " " " 17845 with
	17846
17846	Presser Bar Lifting Lever Rod Chain
62240 9069	" " Spring (flat)
38468 9068	" " Stnd
62244 9070	" Foot (back)
62243 9070	" " (front)
62245 9070	" " Bracket
1175p 9070	" " Hinge Serew
62242 9070	" " Spring
208b 9070	" " Serew
702c 9070	" Stop Screw
62246 - 9070	Presser Foot complete, Nos. 62244, 62243,
	62245 and two each 208p, 702c, 1175p
	and 62242
190p 9074	Presser Foot Screw
574p 9074	Pressure Regulating Thumb Screw
1539p 9079	" " Lock
100,00 0010	Nut
63975 9071	Pulley (loose) 234 in. diam
	" Bushing
17848 9068 2269 9068	" " Position Pin
1202 R 9079	" Cap Screw
1202R 9079 17942 9071	" (tight) 2½ in. diam., with 2269
2022 9068	" Pin
17955	
17955	Pulleys complete, Nos. 1202r, 1206c, 17848, 17854, 17942 and 63975
	11040, 11094, 11542 and 00910

NO.	PLATE	NAME
17853	9072	Starting Lever
1262c		" " Hinge Serew
1662c		" " " Nut
17886	9071	" " Pitman
17854	9072	Stop Cam
17855	9072	" " Interlocking Rod
124784	9071	" " Case
124785		" " " 124784
		with 59771 and two 193p
124905		Stop Cam Interlocking Rod Case 124785 with 63976 and two 12550
62159		Stop Cam Interlocking Rod Case 124905 with 1318p, 17855, 17863, 17864 and 39222
59769	9071	Stop Cam Interlocking Rod Case Bracket
62186		Stop Cam Interlocking Rod Case Bracket
		complete, Nos. 1182E, 4196c, 1204E, 4254c, 1262c, 1508E, 1662c, 17853, 17859, 17861, 17862, 17872, 17873, 59769, 62159 and two 898D
20105		Stop Cam Interlocking Rod Case Bracket
62137		62186 with 39343, 39344 and two 1186F
21828	6976	Stop Cam Interlocking Rod Case Bracket Dowel Pin
50372n	9074	Stop Cam Interlocking Rod Case Bracket Screw
1204 E	9072	Stop Cam Interlocking Rod Case Hinge Screw
17859	9072	Stop Cam Interlocking Rod Case Socket Joint
8081	9074	Stop Cam Interlocking Rod Case Socket
OD CAL	, ,,,,,,,	Joint Cap Screw
39343	9071	Stop Cam Interlocking Rod Case Spring
		(flat)
506820	: 9072	Stop Cam Interlocking Rod Case Spring
		Adjusting Screw
15201	E 9075	Stop Cam Interlocking Rod Case Spring Adjusting Serew Nut
39344	9072	Stop Cam Interlocking Rod Case Spring
99944	9072	Bracket with 1520E and 50682c
1186	F 9074	Stop Cam Interlocking Rod Case Spring Bracket Screw
17861	9072	Stop Cam Interlocking Rod Case Stop
1254	c 9074	Stud
		And the second of the second o

NO.	PLATE	NAME
1508E		Stop Cam Interlocking Rod Case Stop
100011	,,,,,	Stud Screw Bushing Lock Nnt
17862	9072	Stop Cam Interlocking Rod Case Stop
		Stud Spring
59771	9072	Stop Cam Interlocking Rod Case Wearing
		Block
193p	9074	Stop Cam Interlocking Rod Case Wearing
		Block Screw
17863	9072	Stop Cam Interlocking Rod Spring
17864	9072	" " " Stop
1318D	9074	" " Screw
3012	9062	" " Pin
1206c	9075	" " Screw
2102	9076	Tension Disc
1560c	9076	" Regulating Thumb Nut
50148c	9076	" Screw Stud
42336	9076	" Spring
13915	9076	" " Bushing
10145	9076	" Thread Guide
124609	9076	Thread Controller Sleeve
124607	9076	" " Spring
124608	9076	" " Collar with
		1477F
1477r	9074	Thread Controller Spring Collar Set Screw
124892	9076	" " Stud with 32519
124900		" " 124892 with 124893
32519	9076	" Collar Pin
457c	9074	" " Set Serew
124893	9076	" "Thread Guide
124894		Thread Controller complete, Nos. 124607
		to 124609 and 124900
*124632		Thread Nipper (lower) Blade
*124633		" " " Carrier with
		124637
124634	9076	Thread Nipper (lower) Blade Carrier
		124633 with 124632 and two 6037
124615	9076	Thread Nipper (lower) Blade Carrier
		Hinge Stud
124635	9076	Thread Nipper (lower) Blade Carrier
		Holder with 124615
124636	9076	Thread Nipper (lower) Blade Carrier
		Holder Cover
665л	9074	Thread Nipper (lower) Blade Carrier
		Holder Cover Screw
898D	9074	Thread Nipper (lower) Blade Carrier
		Holder Screw

NO.	PLATE			NAMI	E
124637	9076	Thread I	Vipper	(lower)	Blade Carrier Stud
6037	9076	"	44	"	" Rivet
124638	9077	46	44	44	Cam
3351		"	"	"	" Screw
	9074	4:	44	"	Connection
124639		44	46	44	" Cap
124640	9076	46	44		" · " p
1761	o 9074				
		Screw) Constitution Con-
2273	9076	Thread	Nipper	(lower	Connection Cap
		Steady	y Pin		
124641	9077	Thread !	Nipper	(lower)	Connection Exten-
		sion (back)		
999	c 9075	Thread :	Nipper	(lower)	Connection Exten-
		sion (back) I	linge S	erew
917	р 9074	Thread	Nipper	(lower)	Connection Exten-
~1.					
124642	9077	Thread	Ninner	(lower)	Connection Exten-
124042	5011	eion (front)	(10,1,01)	
r(\1.1.1	0075				Connection Exten-
20111	ь 9075	i mead	rapher	Uingo S	crew
4 /4 415	0.055	sion (Minner	Hinge i:	Driving Arm
124643		Thread	Nipper	· (lower	" " Pin.
8554			"	"	1 111 .
124621	9077	"		"	Lever with 237K
8554	9077	"	44	•••	1 111
237	к 9077	"	"	"	Ber Berem
124623	9077	"	44	"	" Shaft
124624	9076	"	44	"	" "Bracket.
1177	7.j. 9074	"	46	"	
		Screw	7,		
1560	e 9076	Thread	Nipper	r (uppei	·) Adjusting Thumb
		Nut.			
62251	9078	Thread	Nipper	r (uppei	r) Body
447	c 9074	44	6.6	44	" Set Screw
5977		"	"	46	Cam with two
0011	1 (/////	50150)c		
50150	nc 9074) Cam Set Screw
210			"	"	Disc
			4.6	"	Releasing Disc
3257:			"	"	" Pin
6225			"	44	
50100		•		"	Screw Stud
13710				-	Spring
6225				4.6	Stud
223	3г 9066		44	"	" Position Screw
13539	9 9078		"	"	" Roller
1354	0 9078	"	4.6	"	" " Pin
6225	4 9078		Nipp	er (upp	er) Stud complete
		Nos.	13539,	13540	and 62253

NO.	PLATE	2		NAME	:		
57076	9078		Nipper ((upper)	Thre	ad Gu	ide
62255		Thread 223r,	Nipper	(upper	·) cor	nolete	. Nos
		223F,	1560c.	13710	. 325	572. 5	0106c
		57076	62251,	32252. (2254	and tw	o 2109
124625	9078	Thread	Take-up	Body	with (52172	0.2102
42808	9078	"	"	Roller		,_1.	
62171	9078	"	"	64	Cap		
3371	p 9078	46	"	"	"	Screw.	
62172	9078	"	"	"	Pin		
124626	9078	Thread	Take-ur	comr	lete.	Nos	337n
		42808,	62171 a	nd 124	625		9010,
6911	F 9074	Thread '	Fake-up	Screw.			
17872	9070	Trip Lev	er				
1196c	9075	" "	Hing	e Screw		• • • • • •	
17873	9078	"	Sprin	g	••••		• • • • •
11821	9074	"	"	Screv	,	· · · · · ·	
17874	9078	Tripping	Point.	DOLO	• • • • •	• • • • • •	• • • • •
190r	9074	"	" S	crew			
124946	9079	Vibrating	r Presser	· Rar	• • • •	• • • • • •	
124947	9078	"	"	" a	nd R	ago P	data
		Threac	l Nippe	r Spri	na R	acc i	Tare
		857r. 1	096r an	d 1258a	, ,	lacket	WILL
124948		Vibrating	Presse	r Bar	and	Faco	Pluto
		Thread	Nipper	Spring	Brack	et.com	nlete
		Nos. 1	1101, 124	1946. I2	24947	and P	24949
1258c	9078	Vibrating	Presse	r Bar	and	Face	Plate
		Thread	Nippe	r Spri	nø B	raeket.	Set
		Screw			. 6	THE RUE	DCt
14101	9078	Vibrating	Presser	Bar Ca	in Sci	ew	
190p	9074	**	66	" Se	rew		
124949	9079	44	"	66 CL.	ring.		
1096 F	9078	44	"	66	" 9	Zarow	
133ғ	9074	"	"	" St	op S	erew	for
		62201					101
442c	9068	Vibrating	Presser	Bar	Stop	Screw	for
		124940.					101
1735 R	9075	Vibrating	Presser	Bar S	ton S	crew 1	Lock
		Nut for	62201				LOUR
1550c	9068	Vibrating	Presser	Bar S	ton S	erew 1	Lock
		Nut for	124940.				OUR

ACCESSORIES

NO.	PLATE				AME
18419		Cylinder	Base	Plate	with two 453c
18420	7006	"			Hinge Connection

NO.	PLATE	NAME
18423	7006	Cylinder Base Plate Hinge Connection
		Hinge Pin
453 c	9074	Cylinder Base Plate Hinge Connection
		Hinge Pin Set Screw
18424	7005	Cylinder Base Plate (hinged) complete,
		Nos. 18419, two each 18420, 18423, three
		wood screws 11/4 in. No. 12 and four
		134p
134r	7006	Cylinder Base Plate Screw
120346	7007	Oiler (copper plated) with 120347
120347	7007	" Sport, 9 in. long
11831	7007	Screw Driver (large)
26026	7007	" (small)
10875	7007	Wreneh for 1518, 1520 and 1662
17905	7007	" " 1681
27662	7007	" " 1254 and 1508

FOOT LIFTER PARTS

NO.	PLATE	NAME
17876	7005	Treadle with 443c
17877	7005	" Pitman Rod (lower)
17878	7005	" " (upper)
17879	7005	" " Clamp with two 161p
16Hr	9074	" " " Serew
17880	7005	Treadle Pitman complete, Nos. 17877 to
		17879
17881	7006	Treadle Shaft
4430	9074	" Set Serew
17882	7006	" Spring
17883	7005	" Stand
17884		Treadle complete, Nos. 17876, 17881 to
		17883 and two wood screws 1 in. No. 10
17885		Treadle and Pitman complete, Nos. 17880 and 17884

FOOT LIFTER CHAIN GUIDE

NO.	PLATE	NAME
65883	9079	Chain Guide Bracket
2461	9079	" " Pulley
65884	9079	" " Pin
65885		Foot Lifter Chain Guide complete, Nos.
		2461, 65883, 65884 and four wood screws
		1 in. No. 10 R. H. O. and A

STARTING LEVER

NO.	PLATE	NAME
13351		Chain, 46 in. to 55 in. long, with 56864 and 56865
	No	ote: When ordering No. 13351, give length required
56864	7007	Chain Hook (large)
56865	7006	" " (small)
17876	7005	Treadle with 443c
17881	7006	" Shaft
443c	9074	" Set Screw
17882	7006	" Spring
17883	7005	" Stand
17884		Treadle complete, Nos. 17876, 17881 to 17883 and two wood screws 1 in, No. 10

TABLE BELT GUIDE

NO. 39218 1686	PLATE 7005 9074	NAME Belt Guide with two 168E " Set Serew
17892 17893	7005 7005	Bracket with two 153E
39219 63973	7005 9069	" Shaft (long) with 17896 and 63973 " " Wick (braided cotton)
39220 63974	7005 9069	" (short) with 17896 and 63974
17896	7006 9074	" " Plug
	9074	Table Belt Guide complete, Nos. 17892,
		39219, 39220, two each 17893, 39218 and three wood screws 1¼ in. No. 12

THREAD UNWINDER

FOR ONE LARGE SPOOL OR ONE LARGE CONE OF THREAO

	PLATE			NAME
225389	8523	Spool	Rest	with 201018c
225388	8523		••	Rod
200383c	9074	• •	**	" Set Screw
201018e	9074	**	••	Set Screw
202490	8523	+4	Straid	l with 200383e

225391	8523	Thrend	Cuide	
		A III Cattl	"	······································
60771	7006	**		
60772		44	"	60771 with 41635
41635	7006	"	44	Bracket with 175E
175E	7006	"	44	" Set Screw
201696j	9079	"	44	Lock Nut
225392	8523	"	44	Rod with 208E and 225393
208E	9074	"	44	" Screw
225393	9079	"	"	" Washer
225394	8523	Thread	Unwir	nder complete, Nos. 201696J,
		20249	0, 225	388, 225389, 225391, 225392
		and t	liree w	rood screws 7/8 in. No. 12
27739	7234	Thread	Cone	(wood) for large cones
225390	7234	"	"	Holder, for inverted cones.
No	OTE: N	los. 2773	9 and	225390 are used with,
		but not i	includ	ed in, 225394
60773		Thread	Unwir	nder with Thread Guide com-
		plete,	Nos.	60772 and 225394

NUMERICAL LIST OF PARTS

NUMERICAL LIST OF PARTS

NO. PLATE	NAME
76p 9075	Gnide Holder Hinge Screw
92n 9075	Hat Support Hinge Screw
99c 9075	Thread Nipper (lower) Connection Exten-
	sion (back) Hinge Screw
100в 9075	Hat Support Lock Screw
133г 9074	Vibrating Presser Bar Stop Screw for 62201
134n 7006	Cylinder Base Plate Screw for 18424
153 г. 9074	Table Belt Guide Pulley Shaft Set Screw
	for 17892
155c 6992	Needle Bar Connecting Stnd Set Screw
	for 2052
160p 9074	Feed Regulator Bracket Cap Screw for
	62221
161b 9074	Treadle Pitman Rod Clamp Screw for
	17879
164p 9074	Face Plate Screw (upper)
164E 9074	Presser Bar Lifting Lever Bracket Screw
	for 62201
168E 9074	Table Belt Guide Set Screw for 39218
175в 7006	Thread Unwinder Thread Gnide Bracket
	Set Serew for 41635
176b 9074	Thread Nipper (lower) Connection Cap
	Serew,
184E 9074	Belt Cover Bracket Serew Stud for 59795
190ъ 9074	Arm Side Cover Screw
190ь 9074	Face Plate Screw (lower)
190n 9074	Knife (upper) Spring Screw
190b 9074	" Bar Connection Screw
190ъ 9074	Looper Shaft Gear Cover Screw
190a 9074	Needle Guard (front) Screw
1905 9074	Presser Foot Screw
1905-9074	Tripping Point Screw for 62215
190ь 9074	Vibrating Presser Bar Screw
193b 9074	Stop Cam Interlocking Rod Case Wearing
	Block Screw for 124785
194c 9064	Knife Lever Screw Stud
196г 6992	Presser Bar Collar Set Screw for 17841
199n 9074	Feed Plate Carrier Bar Screw for 62293
20Sp 9074	Face Plate Thread Retainer Disc Cover
	Screw for 124940
208p 9070	Presser Foot Spring Serew for 62246
208E 9074	Thread Unwinder Thread Guide Rod
	Screw for 225392

NO. PLATE	
217 D 9074	Belt Cover Screw
217р 9074	Thread Nipper (lower) Connection Extension (back) Screw
223r 9066	Knife Bar Driving Lever Lock Stud Set
	Screw for 59734
223 _F 9066	Thread Nipper (upper) Stud Position Serew for 62255
229p 9074	Face Plate Thread Guard Screw for 124940
231f 9074	Feed Plate Carrier Bar Plate Screw
231F 9074	" " Screw
237к 9077	Thread Nipper (lower) Lever Set Screw for 124621
330ь 9078	Cylinder Bottom Cover Screw
335a 907 I	Thread Nipper (lower) Cam Screw for 62215
337р 9078	Thread Take-up Roller Cap Screw for 124626
377c 6992	Needle Bar Connecting Link Hinge Screw for 62283
392н 9074	Face Plate Thread Nipper Disc Cover Serew for 124940
442c 9068	Vibrating Presser Bar Stop Screw for 124940
443c 9074	Starting Lever Treadle Shaft Set Screw for 17876
443c 907 i	Treadle Shaft Set Screw for 17876
446c 9067	Needle Bar Crank Wheel Set Serew for 62235
447c 9071	Looper Shaft Bushing (back) Set Screw.
417c 9074	" " (front) Set Screw
4·17c 907·1	Needle Guard (back) Shaft Bushing Set Screw
447c 9074	Thread Nipper (upper) Body Set Screw
448c 6992	Arm Shaft (upright) Bushing (lower) Set Screw
448c 6992	Arm Shaft (upright) Bushing (upper) Set Screw
453c 9074	Cylinder Base Plate Hinge Connection Hinge Pin Set Serew for 18419
453c 9074	Feed Cam Driving Worm Wheel Set Screw for 17797
453c 9074	Presser Bar Guide Bracket Set Screw for 17842
457c 9074	Thread Controller Stud Set Screw
465c 9067	Looper Shaft Collar Set Screw for 59745.
165c 9067	Needle Guard (back) Cam Set Screw for
-500 0001	62272

NO. PLATE	NAME
465c 9067	Needle Guard (back) Set Screw for 62271
465c 9067	" " " Shaft Collar Set
	Screw for 59761
574n 9074	Pressure Regulating Thumb Screw
602n 9074	Guide Adjusting Screw
6651 9074	Thread Nipper (lower) Blade Carrier
	Holder Cover Screw
691F 9074	Thread Take-up Screw
702c 9070	Presser Foot Stop Screw for 62246
857F 9074	Face Plate Thread Nipper Spring Screw
	for 121917
880E 9074	Arm Screw.
898b 9074	Stop Cam Interlocking Rod Case Socket
	Joint Cap Screw for 62186
898b 9074	Thread Nipper (lower) Blade Carrier
	Holder Screw
904c 9074	Needle Set Screw for 124942
965в 9074	Feed Regulator Bracket Screw
1034b 9074	Cylinder End Cover Spring Screw for
1004 4004	62205
1036c 6976	Arm Shaft (horizontal) Gear Set Screw
1000 0050	for 59703
1096r 9078	Vibrating Presser Bar Spring Screw for
1177 0070	124947
1175b 9070	Presser Foot Hinge Screw for 62246
11771 9074	Thread Nipper (lower) Lever Shuft
1182ы 9074	Bracket Screw.
1186r 9074	Trip Lever Spring Screw for 62186 Stop Cam Interlocking Rod Case Spring
1100F 3074	Bracket Screw for 62137
1190e 9074	Feed Regulator Stop Screw
1191p 9074	" "Thumb Screw
H192c 9074	Feed Cam Set Serew for 62215
H96c 9075	Trip Lever Hinge Screw for 62186
1201ъ 9075	Presser Bar Lifting Lever Hinge Screw
1202 R 9079	Pulley (loose) Cap Screw for 17955
1201E 9072	Stop Cain Interlocking Rod Case Hinge
	Screw for 62186
1206c 9075	Stop Cam Screw for 17955.
1253c 6976	Arm Shaft (upright) Gear (lower) Set
	Screw for 59707
1253e 6976	Arm Shaft (upright) Gear (upper) Set
	Screw for 59708
1253c 6976	Looper Shaft Gear Set Screw for 59707
I254c 9074	Stop Cam Interlocking Rod Case Stop
	Stud Screw Bushing for 62186
1255р 6976	Belt Shifter Clamp Screw for 124905

NO. PLATE	NAME
$1258c_{\odot}9078$	Vibrating Presser Bar and Face Plate
	Thread Nipper Spring Bracket Set Screw
	for 124947
1262c - 9075	Starting Lever Hinge Screw for 62186
1293c 6992	Needle Bar Crank Wheel Position Screw
	for 62235
13186)9074	Stop Cam Interlocking Rod Stop Screw
	for 62159
1329o 9074	Knife (lower) Screw
1329×9074	Needle Bar Thread Nipper Screw
1380ъ 9064	Knife (lower) Thread Guard Screw for 124654
1382⊭ 9075	Knife Bar Driving Lever Hinge Screw
1387c 9064	" Cap (back) Screw
14101 9078	Vibrating Presser Bar Cap Screw for
11101 5010	124948
1441c 9064	Feed Cam Driving Worm Set Screw for
11111. 0001	18415
1442c 9064	Feed Cam Driving Worm Position Screw
11120 0001	for 18415
1477p 9074	Cylinder End Cover Bracket Screw for
- 21111	62205
1477p 9074	Cylinder End Cover Hinge Serew for
	62205
1477F 9074	Thread Controller Spring Collar Set Screw
	for 124608
1508и 9075	Stop Cam Interlocking Rod Case Stop
	Stud Screw Bushing Lock Nut for
	62186
1518E 6992	Needle Bar Connecting Link Hinge Screw
	Nut for 62283
1520 E 9075	Arm Shaft (horizontal) Bushing (back)
	Adjusting Screw Nut
1520⊭ 9075	Stop Cam Interlocking Rod Case Spring
	Adjusting Screw Nut for 39344
1539b 9079	Pressure Regulating Thumb Screw Lock
	Nut
1550c - 9068	Vibrating Presser Bar Stop Screw Lock
	Nut for 124910
1560c 9076	Tension Regulating Thumb Nut
1560c - 9076	Thread Nipper (upper) Adjusting Thomb
	Nut for 62255
1653c 9075	Feed Cam Shaft Nut
1655c 9061	" Regulator Roller and Screw Stud
	Nut for 1953
1662c 9075	Starting Lever Hinge Screw Nut for 62186
1681c: 9075	Knife Bar Driving Lever Hinge Screw Nut

NO.	PLATE	NAME
1735 n	9075	Vibrating Presser Bar Stop Serew Lock
1816	9067	Nut for 62201
		and Stud for 62273
1953	9064	Feed Regulator Roller and Serew Stud with 1655c and 14017, for 17742
2022	9068	Pulley (tight) Pin
2052	6992	Needle Bar Connecting Stud with 155c, for 62283
2102	9076	Tension Disc
2102	9076	Thread Nipper (upper) Disc for 62255
2107	9062	Face Plate Thread Guard for 124940
2269	9068	Pulley (loose) Bushing Position Pin for 17942
2273	9076	Needle Guard (back) Shaft Crank Pin
2273	9076	Thread Nipper (lower) Connection Cap Steady Pin
2461	9079	Foot Lifter Chain Guide Pulley for 65885
3012	9062	Feed Cam Driving Worm Wheel Pin
3012	9062	Stop Cam Pin
4448	6976	Arm Oil Tube, for intermediate bearing
*4449	9062	" Shaft (horizontal) Bushing (front)
		for 62201
4604	9061	Knife Lever Block Rivet
6037	9076	Thread Nipper (lower) Blade Rivet for 124634
8554	9077	Thread Nipper (lower) Driving Arm Pin
8554	9077	" " Lever Pin
8589	9061	Feed Regulator Bracket Dowel Pin
	N	los. 9543 to 9545 for 124940
9513	9062	Face Plate Thread Retainer Disc
9544	9062	" " Cover.
9545	9062	" " " Spring
10145	9076	Tension Thread Guide
10875	7007	Wrench for 1518, 1520 and 1662 (Accessories)
11831	7007	Screw Driver, large (Accessories)
1335 L		Starting Lever Chain, 46 in. to 55 in. long, with 56864 and 56865
13539	9078	Thread Nipper (upper) Stud Roller for 62251
13540	9078	Thread Nipper (npper) Stud Roller Pin for 62254
13710	9078	Thread Nipper (upper) Spring for 62255
13915	9076	Tension Spring Bushing

NO.	PLATE	NAME
14017	9064	Feed Regulator Roller and Screw Stud
1101,	.,,,,,,,	Nut Washer for 1953
16532	6976	Arm Dowel Pin
17703	9062	" Shaft (horizontal) Bushing (back)
*17732		Feed Regulator Bracket Cap for 62221
17742	9065	" " with 1953
17744	9064	" " Hinge Stud
17745	9064	" " Swivel
17797	9063	" Cam Driving Worm Wheel with 453c
17841	6992	Presser Bar Collar with two 196F
17842	6992	" " Guide Bracket with 453c
17843	9069	" Lifting Lever
17845	9069	" " " Rod for 39408
17846		" " " Chain for
17040		
17040	9068	39408
$\frac{17848}{17853}$	9072	Starting Lever for 62186
17854	$\frac{9072}{9072}$	Stop Cain for 17955
17855	$\frac{9072}{9072}$	" " Interlocking Rod for 62159.
17859	$\frac{9072}{9072}$	" " Case Socket
17809	9072	Joint for 62186
17861	9072	Stop Cam Interlocking Rod Case Stop
		Stud for 62186
17862	9072	Stop Cam Interlocking Rod Case Stop Stud Spring for 62186
17863	9072	Stop Cam Interlocking Rod Spring for 62159
17864	9072	Stop Cam Interlocking Rod Stop for
		62159
17872	9070	Trip Lever for 62186
17873	9078	" " Spring for 62186
17874	9078	Tripping Point for 62215
17876	7005	Starting Lever Treadle with 443c, for 17884
17876	7005	Treadle with 443c, for 17884
Nos. 17877 to 17879 for 17880		
17877	7005	Treadle Pitman Rod (lower)
17878	7005	" " (upper)
17879	7005	" " Clamp with two 161c
17880	7005	Treadle Pitman complete for 17885, Nos. 17877 to 17879
	N	os. 17881 to 17883 for 17884
17881	7006	Starting Lever Treadle Shaft
17881	7006	Treadle Shaft
17882	7006	Starting Lever Treadle Spring
17882	7006	Treadle Spring
11004	71700	Troude Kpring

NO.	PLATE	NAME
17883	7005	Starting Lever Treadle Stand
17883	7005	Treadle Stand
17884		Starting Lever Treadle complete, Nos. 17876, 17881 to 17883 and two wood screws 1 in. No. 10
17884		Treadle complete for 17885, Nos. 17876, 17881 to 17883 and two wood screws 1 in. No. 10
17885		Treadle and Pitman complete, Nos. 17880 and 17884
17886	9071	Starting Lever Pitman
17892	7005	Table Belt Guide Bracket with two 153E, for 39221
17893	7005	Table Belt Guide Pulley for 39221
17896	7006	" " " Shaft Plug for
17005	7007	39219 and 39220
17905	7007	Wrench for 1681 (Accessories) Knife Bar Connection Slide Block for
17915	9066	17917
17916	9066	Knife Bar Connection Slide Block Stud for 17917
17917		Knife Bar Connection Slide Block 17915 with 17916, for 62126
17942	9071	Pulley (tight) 21/8 in. diam., with 2269, for 17955
17955		Pulleys complete, Nos. 1202 R, 1206 c, 17848, 17854, 17942 and 63975
18384	9062	Feed Cam Pin
18415	9064	" " Driving Worm with 1441c and 1442c
18419		Cylinder Base Plate with two 453c, for 18424
18420	7006	Cylinder Base Plate Hinge Connection for 18424
. 18423	7006	Cylinder Base Plate Hinge Connection Hinge Pin for 18424
18424	7005	Cylinder Base Plate (hinged) complete, Nos. 18419, two each 18420, 18423, three wood screws 1¼ in. No. 12 and four 134p (Accessories)
18498	9073	Belt Cover
21828	6976	Stop Cam Interlocking Rod Case Bracket Dowel Pin
26026	7007	Screw Driver, small (Accessories)
27662	7007	Wrench for 1254 and 1508 (Accessories)
27739		Thread Cone (wood) for large eones, for 225394

NO.	PLATE	NAME
32519	9076	Thread Controller Stud Collar Pin for
02019	3070	124892
32572	9078	Thread Nipper (upper) Releasing Disc for 62255
34418	9067	Looper Washer for 62298
36634	9064	Knife (upper) Friction Washer
38168	9068	Presser Bar Spring Stud
*39203	9067	Needle Bar Connecting Link for 62283
	N	os. 39218 to 39220 for 39221
39218	7005	Table Belt Guide with two 168E
39219	7005	" " Pulley Shaft (long) with
00-10	• ., ., .,	17896 and 63973
39220	7005	Table Belt Guide Pulley Shaft (short)
00220	1000	with 17896 and 63974
39221		Table Belt Guide complete, Nos. 17892,
00221		39219, 39220, two each 17893, 39218
		and three wood screws 1¼ in. No. 12
0.0000	0000	
39222	9063	Belt Shifter for 62159
39343	9071	Stop Cam Interlocking Rod Case Spring
00044	0080	(flat) for 62137
39344	9072	Stop Cam Interlocking Rod Case Spring
		Bracket with 1520E and 50682c, for
		62137
39408		Presser Bar Lifting Lever Rod 17845 with 17846
41635	7006	Thread Unwinder Thread Guide Bracket
		with 175E, for 60772
42336	9076	Tension Spring
42808	9078	Thread Take-up Roller for 124626
50106c	9078	" Nipper (upper) Screw Stud for
		62255
50111 b	9075	Thread Nipper (lower) Connection Exten-
		sion (front) Hinge Screw
50130c	9075	Knife Lever Hinge Screw
50148c	9076	Tension Screw Stud
50150c	9074	Looper Set Screw for 62231
50150c	9074	Thread Nipper (upper)Cam Set Screw for
		59774
50316p	9075	Knife (upper) 1linge Screw
50333c	9074	Arm Shaft (horizontal) Bushing (back)
		Adjusting Screw
$50372\mathrm{p}$	907-1	Stop Cam Interlocking Rod Case Bracket
		Screw
50682c	9072	Stop Cam Interlocking Rod Case Spring
		Adjusting Screw for 39344

NO.	PLATE	NAME
52015	9067	Looper Shaft Bushing Oil Pad (cotton) for
		62285 and 124694
56015	6976	Arm Oil Tube, for oiling 59705 and 59706
56864	7007	Starting Lever Chain Hook (large) for
		13351
56865	7006	Starting Lever Chain Hook (small) for 13351
57076	9078	Thread Nipper (upper) Thread Guide for 62255
59702	9073	Arm Shaft (horizontal)
59703	6976	" " Gear with two
		1036c
59704	6976	Arm Shaft (upright)
59705	6976	" " Double of Change
59700	6976	" " (upper) " " Gear (lower) with
59707	6976	" " Gear (lower) with
		two 1253c
59707	6976	Looper Shaft Gear with two 1253c
59708	6976	Arm Shaft (upright) Gear (upper) with
		two 1253c
59734	9066	Knife Bar Driving Lever with 223F and
		59735
59735	9066	Knife Bar Driving Lever Lock Stud for
		59734
*59742		Looper Collar for 62231
59745	9067	" Shaft Collar with two 465c
597:17	6992	" Gear Cover
59761	9067	Needle Guard (back) Shaft Collar with two
		465c
59769	9071	Stop Cam Interlocking Rod Case Bracket
		for 62186
59771	9072	Stop Cam Interlocking Rod Case Wearing
		Block for 124785
59774	9078	Thread Nipper (upper) Cam with two
		50150c
59795	9063	Belt Cover Bracket with 184E and 59796
59796	9062	" " Stud for 59795
60771	7006	Thread Unwinder Thread Guide for 60772
60772		" " " " 60771 with
		41635, for 60773
60773		Thread Unwinder with Thread Guide
		complete, for one large spool or one large
		cone of thread, Nos. 60772 and 225394
62111	9062	Cylinder End Cover Bracket Hinge Pin
		for 62205
62125	9064	Knife Bar Cap (back)
62126	9066	" " Connection with 17917

NO.	PLATE	111111
62131		The source is desiring (back) for 0220d.
62137	·	Stop Cam Interlocking Rod Case Bracket
		62186 with 39313, 39344 and two 1186s
62155		Feed Cam Shaft
62159		Stop Cam Interlocking Rod Case 124905
		with 1318b, 17855, 17863, 17864 and 39222, for 62186
62171		Thread Take-up Roller Cap for 124626
62172	9078	" " " Pin for 124625
62186		Stop Cam Interlocking Rod Case Bracket
		complete for 62137, Nos. 1182E, 1196c,
		1204e, 1254c, 1262c, 1508e, 1662c, 17853, 17859, 17861, 17862, 17872,
		17853, 17859, 17861, 17862, 17872,
		17873, 59769, 62159 and two 898p.
62192	9066	Knife Bar Retaining Spring Bracket
*62201		Arm with 4449, 124793 and two 164E
*62202		Cylinder
62203	9063	" Bottom Cover for 62205
62204	9063	" End Cover for 62205
62205		" " 62204 with 1034b,
		62111, 62203, 62206 to 62208 and four
		14770
	N	os. 622 0 6 to 62208 for 62205
62206	9062	Cylinder End Cover Bracket
62207	9062	" " " Hinge
62208	9062	" " Spring.
62211	9062	Face Plate Thread Ninner Dieg for 194040
62212	9062	" " " Cover for
69919	0000	124940
62213 62215	9062 9073	Face Plate Thread Nipper Spring
02213	9073	Feed Cain with two 1192c, seven each
62221	9065	190b, 17874, 124638 and fourteen 335j
02221	9009	Feed Regulator Bracket with 17732 and
62222	9064	two 160p
62226	9064	Feed Regulator Post for 62293
62227	9073	Knife (upper) Spring
62229	9067	" Bur
62230	9064	" Lever
62231	9073	" "Block Looper Shaft with 50150c and 59742
62233	9067	" "Bushing (front) for 124694
62235	9068	Needle Bar Crank Wheel with 416c and
4777	3000	1293c
62236	9067	Needle Guard (back) Shaft
62238	9067	" " Bushing
32239	9068	" " " Crank Spring
		Clank opring

NO.	PLATE	NAME	
62240	9069	Presser Bar Spring (flat)	
	Nos. 62241 to 62243 for 62246		
62241	9070	Presser Foot (back)	
62242	9070	" " Spring	
62243	9070	" " (front)	
62245	9070	" " Bracket for 62246	
62246	9070	Presser Foot complete, Nos. 62241, 62243, 62245 and two each 208p, 702c, 1175p and 62242	
62251	9078	Thread Nipper (upper) Body for 62255	
62252	9078	" " Releasing Pin for	
		62255	
62253	9078	Thread Nipper (upper) Stud for 62254	
62254	9078	Thread Nipper (upper) Stud complete for 62255, Nos. 13539, 13540 and 62253	
62255		Thread Nipper (upper) complete, Nos. 223F, 1560c, 13710, 32572, 50106c, 57076, 62251, 62252, 62254 and two 2102	
62266	9066	Guide	
62267	9066	" Holder	
62268	9066	" " Loek Spring	
62269	9065	Hat Support	
62270	9064	Hat Support Lock	
62271	9067	Needle Guard (back) with two 465c	
62272	9067	" Cam with two 465c	
62273	9067	" " Shaft Crank with	
		1816	
62274	9068	Needle Guard (front)	
62275	9068	Presser Bar	
62283		Needle Bar Connecting Link 39203 with 377c, 1518E and 2052	
62285		Looper Shaft Bushing (back) 62131 with 52045	
62292	9065	Feed Plate Carrier Bar for 62293	
62293		" " 62292 with 199p	
		and 62222	
62294	9064	Feed Plate Carrier Bar Plate	
62298	9067	Looper with 34418	
63973	9069	Table Belt Guide Pulley Shaft (long) Wick (braided cotton) for 39219	
63974	9069	Table Belt Guide Pulley Shaft (short) Wiek	
	55	(braided cotton) for 39220	
63975	9071	Pulley (loose) 23/4 in. diam., for 17955	
63976	9062	Belt Shifter Clamp for 124905	

NO.	PLATE	
65883	9079	Foot Lifter Chain Guide Bracket for 65885
65884	9079	65885 " Pulley Pin for
65885		Foot Lifter Chain Guide complete, Nos. 2461, 65883, 65884 and four wood screws 1 in. No. 40 R. H. O. and A
120346	7007	Oiler (copper plated) with 120347 (Accessories)
120347	7007	Oiler Spout, 9 in, long, for 120346.
	Nos	s. 121607 то 121609 гол 124894
124607	9076	Thread Controller Spring
124608	9076	" " Collar with 1477F
124609	9076	" " Sleeve
124615	9076	" Nipper (lower) Blade Carrier
		Hinge Stud for 124635
124621	9077	Thread Nipper (lower) Lever with 237k
124623	9077	" " " " " " " " " " " " " " " " " " "
124624	9076	" " " " Bracket
124625	9078	" Take-up Body with 62172, for
	17.77.13	124626
124626	9078	Thread Take-up complete, Nos. 337b, 42808, 62171 and 124625.
*124632		Thread Nipper (lower) Blade for 124634
*124633		" " " Carrier with
		124637, for 124634
124634	9076	Thread Nipper (lower) Blade Carrier
124001	2070	124633 with 424632 and two 6037
124635	9076	Thread Nipper (lower) Blade Carrier
		Holder with 424615
124636	9076	Thread Nipper (lower) Blade Carrier
		Holder Cover
124637	9076	Thread Nipper (lower) Blade Carrier Stud
		for 124633
124638	9077	Thread Nipper (lower) Cam for 62215
124639	9077	" Connection
124640	9076	" " " Cap
124641	9077	" " Exten-
124642	9077	sion (back)
124643	9077	sion (front)
124643 124654		Thread Nipper (lower) Driving Arm
124054 124655	9061 9061	Knife (lower) with 124655 and two 1380b
124656	9051	Thread Guard for 124651
124656 124674	9062	" (upper)
1240/4	9002	Arm Side Cover

NO.	PLATE	NAME
124694		Looper Shaft Bushing (front) 62233 with 52045
124748	9066	Knife Bar Retaining Spring
124784	9071	Stop Cam Interlocking Rod Case for 124785
124785	olicon 975-8	Stop Cam Interlocking Rod Case 124784 with 59771 and two 1930, for 124905.
124793	9068	Presser Bar Lifting Lever Bracket for 62201
124892	9076	Thread Controller Stud with 32519, for 124900
121893	9076	Thread Controller Thread Guide for 124900
124894		Thread Controller complete, Nos. 124607 to 124609 and 124900
124900	· · · · · · · · · · · · · · · · · · ·	Thread Controller Stud 124892 with 124893, for 124894
124905	-	Stop Cam Interlocking Rod Case 124785 with 63976 and two 1255p, for 62459
124939	9063	Face Plate for 124940
124939		Face Plate complete, Nos. 208p, 392E,
124940		442c, 1550c, 9544, 9545, 62211, 62212,
		121939, two 9543 and three each 229p
		and 2107
1249-11	9070	Feed Plate
124942		Needle Bar with 904c
124942 124943		" " Thread Nipper
124946		Vibrating Presser Bar for 124948
124947		" " and Face Plate
14.137.17	3010	Thread Nipper Spring Bracket with
		857F, 1096F and 1258c, for 124948
124948		Vibrating Presser Bar and Face Plate
121910	,	Thread Nipper Spring Bracket com-
		plete, Nos. 1410, 124946, 124947 and
		124919
19.10.10	9079	Vibrating Presser Bar Spring for 124948
	3c 9074	Thread Unwinder Spool Rest Rod Set
200000	0071	Screw for 202490
201018	3c 9074	Thread Unwinder Spool Rest Set Serew
901.604	3, 0070	for 225389 Thread Unwinder Thread Guide Lock
201690	3л 9079	Nut for 225394
202490	8523	Thread Unwinder Spool Stand with 200383e, for 225394

NO.	PLATE	NAME

Nos 225388 to 225302 top 225204

	No.	s. 225388 то 225392 гов 225394
225388	8523	Thread Unwinder Spool Rest Rod
225389	8523	" " with 201018c
225390	7234	" "Thread Cone Holder,
		for inverted cones
225391	8523	Thread Unwinder Thread Guide
225392	8523	" " Rod with
		208E and 225393
225393	9079	Thread Unwinder Thread Guide Washer for 225392
225394	8523	Thread Unwinder complete for 60773, Nos. 201696 <i>j</i> , 202490, 225388, 225389, 225391, 225392 and three wood screws 1/8 in. No. 12

ILLUSTRATIONS OF PARTS

PLATE 6976 TULL SIZE

